

# MgCl<sub>2</sub>(2-6)NH<sub>3</sub> sorption behaviour

M. van der Pal

September 2015  
ECN-L--15-074



'Although the information contained in this report is derived from reliable sources and reasonable care has been taken in the compiling of this report, ECN cannot be held responsible by the user for any errors, inaccuracies and/or omissions contained therein, regardless of the cause, nor can ECN be held responsible for any damages that may result therefrom. Any use that is made of the information contained in this report and decisions made by the user on the basis of this information are for the account and risk of the user. In no event shall ECN, its managers, directors and/or employees have any liability for indirect, non-material or consequential damages, including loss of profit or revenue and loss of contracts or orders.'

# MgCl<sub>2</sub>(2-6)NH<sub>3</sub> sorption behaviour

Sicily  
September, 2015

Ryuichi IWATA\*, Takafumi YAMAUCHI, Yasuki HIROTA, Masakazu AOKI and Takashi SHIMAZU




Fig. 3 Clausius-Clapeyron diagram for  $\text{MgCl}_2 \cdot 2/6\text{NH}_3$ .

# Repeated DSC measurements on $\text{MgCl}_2$


---

- Goal: to understand equilibrium & kinetic behaviour  $\text{MgCl}_2(2-6)\text{NH}_3$
- Approach:
  - for equilibrium conditions & thermodynamic properties:
    - Measure HP-DSC signal for a range of DSC-scanning rates (0.5 to 10 K min<sup>-1</sup>)
    - Determine on-set temperatures of peaks
    - Assume: on-set temperature of sample is independent of scan-rate
    - ⇒ if measured  $T_{\text{onset}}$  varies with scan-rate: extrapolate to scan-rate = 0 to obtain the sample's onset-temperature = equilibrium temperature
    - Clausius-Clapeyron + onset temperatures & pressures yield  $\Delta S$  &  $\Delta H$  values

for kinetics:

- Use LDF-model based on pressure difference between eq pressure and actual pressure
- Determine  $k$ ,  $E_a$  and  $n$ :  $dx/dt = k \cdot (1-x)^n \cdot e^{-E_a/RT} \cdot \ln(P_{\text{eq}}/P_{\text{dsc}})$


# DSC results – equilibrium points



On-set temperature(°C) as a function of scan-rate (K/min) for synthesis (blue) and decomposition of MgCl<sub>2</sub>(2-6)NH<sub>3</sub> at 1(left) and 5(right) bar NH<sub>3</sub>

- Eq values Bevers
- Eq values ECN

Ryuichi IWATA\*, Takafumi YAMAUCHI, Yasuki HIROTA, Masakazu AOKI and Takashi SHIMAZU



Data ECN: Clear effect of hysteresis

Data Iwata: no hysteresis

What causes this difference?


Fig. 3 Clausius-Clapeyron diagram for  $\text{MgCl}_2 \cdot 2/6\text{NH}_3$ .

# Comparing measuring techniques

---

Bervers/ECN: HP-DSC: Equilibrium value is found by taking the onset temperature of DSC-peak:

This gives the temperature at which the  $\text{MgCl}_2$  **starts** to adsorb/desorb  $\text{NH}_3$



# Comparing measuring techniques

Iwata: Fixed volume is filled with ammonia and then connected to a volume containing to  $MgCl_2$  sample

The pressure is measured as function of time until equilibrium pressure has been reached, i.e. the pressure at the **end** of the sorption process





Fig. 2 Schematic of the experimental set-up. 7


# If you put this in a CC diagram (adsorption)



Behavior opposite to:


- Absorption
- Physisorption (isosteres)
- Metal hydrides (slope)

# Ammonia-salt experiment from 2008 (ISHPC2008, Seoul)




flow  $\text{NH}_3$ : 50 to 250 ml<sub>n</sub>/min


# Example result for $\text{LiCl}(1-3)\text{NH}_3$



# Results for $\text{MgCl}_2$ @90°C



# Results for $\text{MgCl}_2$ @90°C



# So what do we know?:


---

- DSC measurements show hysteresis for  $\text{MgCl}_2(2-6)\text{NH}_3$
- Iwata measurements show no hysteresis
- Apparently hysteresis occurs at start of sorption
- Pressure measurements with MFC are in line with these observations:


(if  $P_{\text{eq}} \downarrow$  after initial adsorption, driving force  $(P - P_{\text{eq}}) \uparrow$ ,  
 $d\text{NH}_3_{\text{sorbed}}/dt \uparrow$  and if  $d\text{NH}_3_{\text{sorbed}}/dt > \text{MFC} \Rightarrow P \downarrow$ )

# What causes this behavior?

- Poor kinetics?: if so, why no (big) difference in effect of scan-rate for 1 vs 5 bar (i.e. relative low vs high T)?:  $k = k_0 \exp(-E_a/RT)$  and why hysteresis when extrapolating to scan-rate is 0?
- Some sort of crystal structure change?: if so: why do repeated measurements show very similar HP-DSC curves? (whilst the average crystal size reduces over # of cycles)
- Or ... ?



# Can it be explained from this?



*Mechanistic model for the sequence of  $MgCl_2-NH_3$  sorption reactions. A-F refer to the  $MgCl_2(6-2)NH_3$  reactions. source (Sørensen et al., 2008)*


# To wrap it up:

---

- Hysteresis in  $\text{MgCl}_2(2-6)\text{NH}_3$  sorption confirmed (but slightly less than reported by Bevers, 2007)
- Hysteresis effect apparently only for the first amounts of  $\text{NH}_3$  adsorbed (down to a few %?)
- Hysteresis seems quite independent of temperature so should we exclude kinetics?
- Could it be related to (change in) crystal structure/reaction mechanism?

## Application(s):

- Are there other materials that show similar behavior?
- What would be an accurate method for determining P-T diagram as a function of amount adsorbed? Is it/can it be a function of state at all??
- Can we somehow take advantage of this behavior?
- Sorption heat pump performance better if  $0 \gg x \gg 1$  ?!

A photograph of an industrial skyline at sunset. The sky is a gradient of orange and blue. Several tall, dark smokestacks are silhouetted against the sky. The buildings and structures are dark, with some lights visible. The foreground is a body of water that reflects the sky and the industrial structures.

~~Questions?~~Answers!?

**ECN**

Westerduinweg 3  
1755 LE Petten  
The Netherlands

P.O. Box 1  
1755 LG Petten  
The Netherlands

T +31 88 515 4949  
F +31 88 515 8338  
info@ecn.nl  
www.ecn.nl